



Installation and Operation

hurrySCAN[®] 10 (ID# 112466)
digital, 1064 nm,
with $f = 254$ mm Objective (ID# 100832)



SCANLAB AG
Siemensstr. 2a
82178 Puchheim
Germany

Tel. +49 (89) 800 746-0
Fax: +49 (89) 800 746-199

info@scanlab.de
www.scanlab.de

© SCANLAB AG 2008

(Doc. Rev. 2.6 e - June 20, 2008)

SCANLAB reserves the right to change the information in this document without notice.

No part of this manual may be processed, reproduced or distributed in any form (photocopy, print, microfilm or by any other means), electronic or mechanical, for any purpose without the written permission of SCANLAB.

hurrySCAN® is a registered trademark of SCANLAB AG.

Other mentioned trademarks are hereby acknowledged as properties of their respective owners.

Table of Contents

1	Introduction	5
1.1	Product Overview	5
1.2	Unpacking Instructions and Typical Package Contents	5
1.3	I.D. Plate	5
2	The hurrySCAN® 10 – Principle of Operation	6
2.1	Dynamic Positioning Laser Beams	6
	Customized Optical Configuration	6
2.2	Scan Head Control	7
	Data Transmission between the Controller and the Scan Head	7
	Position Signals, Image Field and X-Y Reference System	8
	Status Signals	9
2.3	Internal Protective Functions	11
	Assuring Safe Operating Temperatures	11
3	Safety During Installation and Operation	12
3.1	Operational Guidelines and Standards	12
3.2	Laser Safety	13
3.3	Electrical Safety	15
4	Installation	16
4.1	Checking the Specifications	16
4.2	Mounting the Objective	16
	Objective Holder	16
	Objective	17
4.3	Layout and Dimensions	18
4.4	Mounting the Scan Head	22
4.5	Electrical Connections	23
	Power Supply	23
	Data Cable Guidelines	24
4.6	Operating and Storage Conditions	25
5	Start-up and Operation	26
5.1	Checking the Installation	26
5.2	Checking the Laser Parameters	26
5.3	Adjustment and Alignment	27
5.4	Checking the Parameters of Application Software	28
5.5	Safe Start-up and Shutdown Sequences	28
6	Optimizing the Application	29
6.1	Dynamic Positioning with Galvanometer Scanners	29
6.2	Optimum Environmental Conditions and Automatic Self-Calibration	30
6.3	Process Monitoring	30
	Software Monitoring	30
	Optical Process Monitoring	30
7	Routine Maintenance and Customer Service	31
7.1	Routine Maintenance of the Optical Surfaces	31
	Routine Maintenance of the Mirrors	31
	Routine Maintenance of the Objective's Optical Surface	31
7.2	Customer Service	32



8	Troubleshooting	33
9	hurrySCAN® 10 Technical Specifications	34
9.1	Electromagnetic Compatibility	35

1 Introduction

This operating manual describes the hurrySCAN® 10 scan head with ID number 112466 together with an objective (ID number 100832).

The manual is a part of the product. Please read these instructions carefully before you proceed with installing and operating the scan head. In particular observe all safety guidelines in this manual. If there are any questions regarding the contents of this manual, please contact SCANLAB (see [page 32](#)).

Keep the manual available for servicing, repairs and product disposal. This manual should accompany the product if ownership changes hands.

SCANLAB reserves the right to update this operating manual at any time and without notification.

1.1 Product Overview

The hurrySCAN® 10 scan head with ID number 112466 is designed for positioning laser beams with a wavelength of 1064 nm and is equipped with a 10 mm aperture.

The scan head is designed for digital signal transfer via the integrated digital interface.

The objective with ID number 100832 has a focal length of $f = 254$ mm and is designed for a wavelength of 1064 nm.


The technical specifications of the product are summarized on [page 34](#).

1.2 Unpacking Instructions and Typical Package Contents

- ▶ Carefully remove the scan head from the package.
- ▶ Protect the scan head from dust and other contaminants.
- ▶ Keep the packaging, so that in case of repair the scan head can be properly repackaged and returned to SCANLAB.
- ▶ Also remove all other articles from the package. Check that all parts have been delivered. Please refer to the corresponding packaging list. A scan head package typically includes a product test protocol with test data. For mounting an objective an objective mounting set may be included in the package or already mounted to the scan head. For controlling the scan head, an RTC® control board may be included in the package.

1.3 I.D. Plate

The scan head's I.D. plate (see [figure 1](#)) with the scan head's serial number is found on the housing.




I.D. plate with serial number (SN)

2 The hurrySCAN® 10 – Principle of Operation

2.1 Dynamic Positioning Laser Beams

The primary tasks of an X-Y scan head are to deflect a laser beam in the X-Y directions and to focus the beam onto the working plane.



Basis of Operation: beam deflection via two galvanometer scanners

The beam deflection task is realized with the help of two tiltable deflection mirrors (see figure 2). The beam enters the scan head through the input aperture and is first deflected in the Y direction by mirror 1 attached to galvanometer scanner 1. The beam then goes on to be deflected in the X direction by mirror 2 attached to galvanometer scanner 2. The resulting deflection angles can be precisely and high-dynamically adjusted by controlling the positions of the galvanometer scanners.

Focusing the beam onto the working plane can be achieved with the help of a scan lens fitted to the scan head's beam exit hole. If an F-Theta objective is used, the position of the focal point on the image field will be directly proportional to the angle of incidence of the beam.

Alternatively, focusing of the beam can be realized with the help of a dynamic focusing system (for instance, SCANLAB's varioSCAN 20) positioned in front of the scan head's entrance aperture.

Customized Optical Configuration

To obtain optimum optical performance for a particular laser application, the scan head's optical configuration must meet the requirements of the application and the used laser system. To achieve optimum reflectivity at the mirrors, SCANLAB therefore selects mirror coatings appropriate for the wavelength and power of the user's laser. The size of the mirrors or the scan head's aperture is selected in accordance with the desired spot size and scan speed. The spot size is also influenced by the objective, which is also selected in accordance with the desired field size (or working distance A between the laser input and the image field) as well as the wavelength and power of the user's laser.

The user, on the other hand, has to ensure that the parameters of the entering laser beam (wavelength, power density and diameter) match the specifications of the scan head.

First the coatings of the deflection mirrors are designed for a defined wavelength or wavelength range. If the wavelength of the employed laser deviates from the specified value, the mirrors will not work properly and can be destroyed.

Second for the mirror coatings also the allowed laser rating is defined. If the specified values are exceeded, destruction of the coatings might result (also see section "Checking the Laser Parameters" on page 26).

In addition the deflection mirrors are intended for a specific beam diameter and a maximum allowed scan angle. If the beam diameter or the scan angle exceeds the specified maximum values, vignetting of the beam can occur. The beam is then no longer fully deflected by the mirrors or can no longer fully pass through the objective. A portion of the beam is then absorbed by the scan head, resulting in a loss of power density at the edges of the image field. Furthermore, the interior of the scan head and the objective might be damaged due to the absorption of laser radiation.

The amount of possible power loss depends, among other things, on the beam profile of the employed laser. For a Gaussian beam profile, beam vignetting is insignificant when the scan angle of each mirror does not exceed the *maximum allowed scan angle* defined on [page 34](#) and when the diameter of the beam doesn't exceed the specified aperture.



Caution!

- Make sure the aperture and the coatings of the deflection mirrors meet the requirements of your application (see "Technical Specifications" on [page 34](#)). For information on tolerances and deviations, please contact SCANLAB.
- Make sure that the focal length, the typical image field size and the wavelength of the objective meet the requirements of your application. If this is not the case, then please contact SCANLAB.
- Check if the wavelength of the input beam and the maximum ratings for beam diameter and laser power match the specifications of the scan head (see [page 34](#)).
- When using scan angles larger than the *maximum allowed scan angle* indicated on [page 34](#), some vignetting inside the scan head and the objective can occur and damage to the interior of the scan head might result. If your application requires larger scan angles, then please contact SCANLAB.
- The maximum allowed scan angle is derived from the geometric and optical data of the employed components (see the [section "Customized Optical Configuration" on page 6](#)). In some cases, particularly with sufficiently small calibration angles, the maximum allowed scan angle can be larger than the maximum adjustable angle. In such cases, the specified maximum allowed scan angle has no practical relevance.

2.2 Scan Head Control


Data Transmission between the Controller and the Scan Head

The controller and the scan head are interconnected via a serial interface for digital data transfer. Data transmission follows the XY2-100 protocol. In the process, essentially the following signals are transferred:

- The controller delivers position values, i.e. set values for the X and Y axes as well as (optionally) the Z axis.
- The scan head generates a status signal to be returned to the controller.
- Two additional channels transmit the data transport synchronization signal and a clock signal.

Figure 3 shows the timing of the clock signal (CLOCK), the synchronization signal (SYNC) and the three data channels (CHAN1/CHAN2/CHAN3).

Every 10 μ s, three 20-bit words (3 control bits, 16 data bits, 1 parity bit) are transmitted serially as differential signals.



Timing diagram of the serial interface signals

Position Signals, Image Field and X-Y Reference System

Position signals are digitally transferred from the controller to the scan head.

Figure 4 shows the definition of the X-Y reference system which is used for the position signals transmitted to the scan head. The orientation of the axes corresponds to the orientation used by the RTC[®] boards from SCANLAB: The Y axis points in the opposite direction of the entry beam (and the Z axis in the opposite direction of the exit beam). Consequently: Scanner 1 deflects the beam in the Y direction, Scanner 2 in the X direction.

The scan head is calibrated in such a way that for a scan angle of 0.408 rad optically with excursion in the negative axis direction the bit-value "1311" has to be transmitted, for the neutral position (null point) the bit-value "32768, and for a scan angle of 0.408 rad optically with excursion in the positive axis direction the bit-value "64225".


The maximum adjustable scan angle is $(1 / 0.96)$ larger than the calibration angle. The input signal values for the maximum adjustable image field points (see figure 4) are listed in the following table.

Position	X bit-Value (CHAN2)	Y bit-Value (CHAN1)
0	32768	32768
1	65535	32768
2	65535	65535
3	32768	65535
4	0	65535
5	0	32768
6	0	0
7	32768	0
8	65535	0

Vignetting can occur at a particular scan angle dependent on the specific scan head and objective. The laser beam is then partially blocked within the scan head or objective, which results in transmission losses. The higher the power loss, the greater is the risk of damage to the scan system. In view of this, the technical specifications page 34 include not only the calibration angle, but also the maximum allowed

scan angle. This is not the same as the maximum adjustable scan angle. To avoid scan system damage, make sure the maximum allowed scan angle is never exceeded.

The maximum allowed scan angle is derived from the geometric and optical data of the employed components (see the section "Customized Optical Configuration" on page 6). In some cases, particularly with sufficiently small calibration angles, the maximum allowed scan angle can be larger than the maximum adjustable angle. In such cases, the specified maximum allowed scan angle has no practical relevance.



Positions in the image field

Figure 4 also depicts the pillow-barrel-shaped distortion of the square image field and shows the orientation of this distortion with reference to the axes. The field distortion is caused by the beam path within the scan head and by the characteristics of the objective. It must be compensated by the controller.

If you use a SCANLAB RTC[®] interface board or an RTC[®] SCANalone standalone board for controlling the scan head, the field distortion is compensated automatically. Before data values are transferred to the scan head, the values are transformed by the RTC[®] boards with the help of a correction table. A

correction table specific for your system is included in the RTC[®] software package or can be ordered from SCANLAB (also refer to the RTC[®] manual). You can use positive and negative coordinate bit-values (–32768 to +32767) of an ideal image field, based on the reference system shown in [figure 4](#), with the origin (zero point) in the center of the image field. The RTC[®] board calculates the corresponding input values and transfers them to the scan head.

The image field size, as well as the working distance A between the input laser beam and the nominal working plane, depend on various factors – among them the focal length of the objective and the aperture of the scan head. The divergence of the input beam also has an influence on the working distance A.

When used with a collimated input beam, the hurrySCAN[®] 10 in combination with the delivered objective (focal length $f = 254$ mm) with working distance $A = 390$ mm produces a typical usable square image field of (170×170) mm².

Calculation of the typical image field size is based on a scan angle of ± 0.349 rad optically. Possible image field limitations due to vignetting or imaging deficits are considered (see the [section "Customized Optical Configuration" on page 6](#)). Calibration angles big enough to produce larger-than-specified image fields might be possible in some cases. To avoid scan system damage, make sure the maximum allowed scan angle is never exceeded.

Status Signals

The scan head provides three status signals available via the XY2-100 protocol. If you use a RTC[®] board, then these status signals can be evaluated via the GET_HEAD_STATUS command.

- PWROK (i.e. "Power OK")
PWROK = 0 signifies a problem in the power supply or a protective action by the electronics. Upon power-up, the PWROK signal is initially 0. After a few seconds (when the electronic components have reached a stable operating state) the PWROK signal then switches to 1. If, upon powering up, the PWROK signal doesn't switch to 1 within several seconds or if the signal switches from 1 to 0 during operation, then **the laser must be turned off immediately**. Under some circumstances the system could deflect the laser beam in an unintended direction, which may cause health hazards and severe equipment damage. The system should be checked immediately to determine the cause.
Switching of the PWROK status signal from 1 to 0 during operation can be caused, for example, by a defective power supply (also see [section "Power Supply" on page 23](#)).
- The PWROK status signal also switches from 1 to 0, if the galvanometer scanner's temperature exceeds a critical value due to excessive load or excessive environmental temperature (see [page 11](#)).
- TempOK (i.e. "Temperature OK")
The TEMPOK signal always switches from 0 to 1 when the operating temperature has been reached (which might take a few minutes). If, during operation, the galvo temperature drops below its minimum operating temperature or exceeds a maximum allowable temperature, the TEMPOK signal will switch to 0. In this case, system operation does not need to be stopped immediately, but large drift or other side-effects may occur.

If system operation is not stopped and the scanner temperatures then reach a still higher critical value, then the built-in temperature control mechanism will switch off the galvanometer scanner drive stages to avoid heat-induced damage to the scanners or the head (see [page 11](#)).

If the scanner temperature drops again below the power-down threshold, the scanner drive stages are automatically restarted.

- PosAck (i.e. "Position Acknowledge")
PosAck = 1 signifies that the difference between the set value and the real position is less than 0.5% of the maximum adjustable image field size (see [page 8](#)). The PosAck signal normally switches to 1 within a few seconds after power-up.

2.3 Internal Protective Functions

Assuring Safe Operating Temperatures

If the scanners are driven for long periods of time at high positioning speeds or if the application includes a high rate of vector changes, the correspondingly high current consumption of the galvanometer scanners can lead to excessive temperatures – especially in the case of insufficient cooling, for instance due to a weak thermal link to the machine.

To prevent damage to the scanners, the hurrySCAN® 10 provides a two-stage temperature control mechanism.



Caution!

- ▶ The user must ensure that the application program evaluates the temperature control signals correctly, as described below.

Stage 1: Temperature Status Warning

The temperature status signal TempOK indicates that the scanner is operating at a safe temperature level. During normal operation, the signal is 1.

If the scanner temperature rises above a certain value or drops below a minimum value, then the TempOK signal switches to 0. SCANLAB recommends to only operate the scan system while the TempOK signal is 1. If the TempOK signal switches to 0 during operation, system operation should be stopped and the system should be checked to determine the cause. If system operation is not stopped, large drift or other side-effects may occur.

- ▶ The application program must repeatedly check the TempOK signal during operation.

Stage 2: Critical Temperature Shutdown

In addition to the temperature status warning, the following scanner protective function is implemented:

If a scanner's temperature rises above the critical value for temperature status warning and reaches a second, still higher critical value, then

- the PowerOK status signal switches from 1 to 0,
- the scanner's output stage is turned off to prevent damage to the scanner. In this situation, the scanner's position is stationary and no longer under programmatic control.

If the scanner's temperature drops again below the power-down threshold, the scanner's drive stage is automatically restarted and the scan head will resume normal operation.



Caution!

- ▶ If the PowerOK signal switches to 0, laser power must be switched off immediately. Otherwise, health hazards and severe equipment damage can occur due to uncontrolled laser radiation.

3 Safety During Installation and Operation

To reduce the risk of injury, please observe the following guidelines.

The safety and warning notices in this manual are indicated by a symbol set against a gray background:



Instructions that may affect a person's health are marked with a warning triangle next to the word "Danger".



Instructions that recommend appropriate use of this device or warn of damage that may occur to it are identified by a circle with an "X" in it, next to the word "Caution".

3.1 Operational Guidelines and Standards

When operating the scan head, the following guidelines and standards should be followed:

- EC Guideline 73/23/EEC
Low Voltage Directive
(including amendment 93/68/EEC)
- EC Guideline 89/336/EEC
Electromagnetic Compatibility
(including amendments 91/263/EEC, 92/31/EEC, 93/68/EEC and 2004/108/EU)
- EC Guideline 98/37/EU
Machinery Directive
- EN 60204-1 (November 1998)
Safety of Machinery – Electrical Equipments of Machines, Part1: General Requirements
(also see similar general machinery safety standards such as VDE 0113-1, IEC60204-1 or ANSI B11.19 Machine Tools – Safeguarding When Referenced by Other B11 Machine Tool Safety Standards-Performance Criteria for the Design, Construction, Care and Operation)
- EN 60825-1 (October 2003)
Safety of Laser Products, Part 1: Equipment Classification, Requirements and User's Guide
(also see similar general laser safety standards such as VDE 0837-1, IEC 60825-1, Safety of Laser

Products - Part 1: Equipment Classification, Requirements, and User's Guide, 21 CFR 1040, Laser Product Performance Standard or ANSI Z136.1 Standard for the Safe Use of Lasers)

- EN 12626
Safety of Machinery - Laser Processing Machines - Safety Requirements
(also see similar laser materials processing system safety standards such as ISO 11553, Safety of Machinery - Laser Processing Machines - Safety Requirements, IEC 60825-4, Safety of Laser Products - Part 4: Safety of Laser Products or ANSI B11.21-1997, Machine Tools Using Lasers for Processing Materials - Safety Requirements for Design, Construction, Care, and Use)

Additional application-dependent guidelines and standards may apply.

Complying with the Relevant Standards for the CE Label

The hurrySCAN® 10 is delivered as an OEM component conceived of for integration into a laser scan system.

The system manufacturer bears the responsibility for complying with the standards and guidelines required for equipment usage and for the CE label.

Scan Head Conformity to EC Guidelines for Electromagnetic Compatibility (EMC)

The scan head is in conformance with EC guidelines 89/336/EEC (electromagnetic compatibility).

Electromagnetic fields that exceed these standards can affect the operation and operating safety of the scan head and therefore require special shielding.

For more information, see [the section "Electromagnetic Compatibility" on page 35](#).

3.2 Laser Safety

This scan head is designed to be operated in conjunction with a laser. Therefore, all applicable rules and regulations for safe operation of lasers must be known and applied when installing the scan head and operating the system in which it is used. Since SCANLAB has no influence over the employed laser or the overall system, the customer is solely responsible for the laser safety of the entire system.



Danger!

- Safety regulations may differ from country to country. The customer bears sole responsibility for compliance with all applicable safety regulations of their respective regulatory jurisdiction.

Shutter

The scan head has no shutter and there is no device to decrease the laser output power. It is the responsibility of the customer to include such a device in the system in a way as to comply with all regulations. The observance of laser safety must be ensured for the entire system.

Maintenance

During maintenance of the laser equipment, the class of the laser can increase. Therefore, the customer must take suitable protective measures.

Warning Symbols

The area where the emerging beam is harmful must be marked with a warning symbol indicating the class of the employed laser – in accordance with IEC 60825-1 laser safety requirements. In addition, a warning symbol must be placed at the emitting aperture of the laser system. The table on [page 14](#) shows the appropriate warning symbols for the various laser classes specified by IEC 60825-1 (or EN 60825-1 / VDE 0837 T1).



Danger!

- During assembly or operation of the scan head, never stare directly into the laser beam or its deflected radiation. Keep all parts of the body away from the laser beam and its path. Routine maintenance should be performed as described in "[Routine Maintenance of the Optical Surfaces](#)" on [page 31](#) and all safety instructions should be observed!
- Adjust the output beam path of the scan head by means of a Class 2 laser. If this is not possible, the laser should be operated at the lowest power. Avoid dangerous deflected radiation!
- The risk of hazardous deflected radiation can increase when optical instruments are used in combination with the scan head.
- Before checking the scan head, make absolutely certain that the laser and scan head are turned off!
- Cover the path of the laser beam via an appropriate protecting case to block laser radiation!
- Do not obstruct the movement of the scan head's mirrors in any way. When the scan head is turned on, the mirrors must not be touched at all!
- Closely follow all IEC 60825-1 laser safety requirements and other applicable accident prevention regulations of your respective regulatory jurisdiction.
- Wear appropriate eye protection at all times.
- Always turn on the PC controller and the scan head's power supply first before turning on the laser. Otherwise the laser beam might be reflected in an arbitrary direction.

Laser Classes Specified by IEC 60825-1 (or EN 60825-1 / VDE 0837 T1)

Visible Laser Radiation	Invisible Laser Radiation	Potential Hazards
LASER CLASS 1	LASER CLASS 1	Class 1: This laser radiation is not harmful; is eye-safe.
 LASER RADIATION DO NOT STARE DIRECTLY INTO THE BEAM WITH OR WITHOUT OPTICAL INSTRUMENTS LASER CLASS 1 M	 INVISIBLE LASER RADIATION DO NOT STARE DIRECTLY INTO THE BEAM WITH OR WITHOUT OPTICAL INSTRUMENTS LASER CLASS 1 M	Class 1 M: Exposure to this radiation is harmful to the eyes if optical instruments are used to reduce the cross section of the laser beam. If this is not the case, this laser radiation is not harmful; is eye-safe.
 LASER RADIATION DO NOT STARE DIRECTLY INTO THE BEAM LASER CLASS 2		Class 2: This laser radiation is in the visible spectrum of 400 to 700 nm. Exposure to this radiation for less than 0.25 s is not harmful to the eyes. It is eye-safe due to the eye's natural aversion response and blink reflex.
 LASER RADIATION DO NOT STARE DIRECTLY INTO THE BEAM WITH OR WITHOUT OPTICAL INSTRUMENTS LASER CLASS 2 M		Class 2 M: This laser radiation is in the visible spectrum of 400 to 700 nm. Exposure to this radiation is harmful to the eyes if optical instruments are used to reduce the cross section of the laser beam. If this is not the case, exposure to this radiation for less than 0.25 s is not harmful to the eyes and is eye-safe due to the eye's natural aversion response and blink reflex.
 LASER RADIATION AVOID EXPOSURE OF THE EYES LASER CLASS 3 R	 INVISIBLE LASER RADIATION AVOID EXPOSURE TO THE LASER BEAM LASER CLASS 3 R	Class 3 R: This laser radiation is harmful to the eyes. Eye exposure exceeds the maximum allowable value.

Visible Laser Radiation	Invisible Laser Radiation	Potential Hazards
 <p>LASER RADIATION AVOID EXPOSURE TO THE LASER BEAM LASER CLASS 3 B</p>	 <p>INVISIBLE LASER RADIATION AVOID EXPOSURE TO THE LASER BEAM LASER CLASS 3 B</p>	<p>Class 3 B: This laser radiation is harmful to the eyes and in some cases to the skin.</p>
 <p>LASER RADIATION AVOID ANY EXPOSURE OF THE EYES OR THE SKIN TO DIRECT OR SCATTERED RADIATION LASER CLASS 4</p>	 <p>INVISIBLE LASER RADIATION AVOID ANY EXPOSURE OF THE EYES OR THE SKIN TO DIRECT OR SCATTERED RADIATION LASER CLASS 4</p>	<p>Class 4: This laser radiation is very harmful to the eyes and skin. Stray radiation can also be dangerous. This radiation can cause fire or explosion and the generation of toxic gases or vapors.</p>

3.3 Electrical Safety

Power is furnished to the scan head by a user-supplied low voltage power supply. The power supply must meet the following mains insulation requirements:

- If the connectors are covered and cannot be reached without tools from the outside, single insulation between the mains and the low voltage circuit is sufficient. The mains insulation must be able to withstand a test voltage of 2 kV AC applied between the mains and the low voltage circuit.
- If the connectors can be reached from the outside, double or reinforced insulation between the mains and the low voltage circuit is necessary. The mains insulation must be able to withstand a test voltage of 4 kV AC applied between the mains and the low voltage circuit.

Additional application-dependent guidelines and standards may apply.

4 Installation

Follow each step for preparation, mounting and electrical connection in the correct order as described in this chapter.



Danger!

- Make sure all components of the system (laser, controller, power supply, computer) are switched off before installation.
- During installation of the scan head, never stare directly into the laser beam or at any of its deflected radiation.
- Never place parts of the body into the direct path of the laser or its deflected radiation.
- After the scan head has been mounted, there is a cone-shaped hazardous laser output area. Do not stare into the laser or its deflected radiation. Keep all parts of the body away from the laser beam.
- Always turn on the PC controller and the scan head's power supply first before turning on the laser. Otherwise the laser beam might be reflected in an arbitrary direction.



Caution!

- Carefully take the scan head out of the packaging.
- The objective is fragile and can be damaged by mechanical pressure. Never place the scan head on top of the objective.
- Protect the scan head and the objective from dust and other contaminants.
- Never touch the optical surfaces of the deflection mirrors or objective. Always use gloves and/or special lens cleaning tissues when handling the optical components.
- Follow the procedures in [chapter 7.1](#) for periodically checking and cleaning the optics.

4.1 Checking the Specifications

Make sure the specifications of the scan head meet the requirements of your application (see "Technical Specifications" on [page 34](#)). If your application requires other specifications, then please contact SCANLAB.

4.2 Mounting the Objective

If the scan head is to be operated with an objective which is not factory-installed (or if an already-mounted objective is to be exchanged), then proceed as described in the following sections.

Objectives are mounted either directly or via an objective holder onto the housing's beam exit side. Many objectives require a mounting set, which (in addition to an objective holder) can include components for securing the objective and objective holder, as well as seal rings and space rings to ensure a safe distance between the objective and the deflection mirrors. Different objectives might require different mounting sets. Appropriate objective mounting sets are attached on the scan head, included with the objective, or obtainable from SCANLAB.

Objective Holder

If the objective mounting set includes an objective holder, install it as follows.

- ▶ Carefully remove (e.g. with a small screw driver) any protective covers from the scan head's objective opening.
- ▶ Some setups require installation of one or more seal rings between the housing and the objective holder. Check for corresponding accessories in the objective mounting set.
- ▶ Place the objective holder (with its form-fitting bottom side) in the beam exit opening. Ensure that the objective holder is correctly positioned. A tilted objective holder can produce unintended beam paths.
- ▶ Secure the objective holder onto the beam exit side via four screws.

Objective



Caution!

- Before installing the objective, verify its compatibility with the mounted objective holder or beam exit threads. Otherwise, damage to the objective and scan head mirrors may result. In the event of questions, contact SCANLAB.

Before mounting, inspect the objective for scratches, lens defects and dirt. If necessary, clean as described in "[Routine Maintenance of the Optical Surfaces](#)" on page 31.

Mount the objective as follows:

- ▶ Carefully remove (e.g. with a small screw driver) any protective covers from the objective holder or the scan head's objective opening.
- ▶ Remove the protective cover from the objective's beam entrance side.
- ▶ Some setups require installation of one or more seal rings between the objective holder and the objective. Seal rings should be lightly lubricated (with vacuum grease). Otherwise, threading of the objective might be very difficult. Additionally, some setups require installation of one or more space rings between the objective holder and the objective to ensure a safe distance between the objective and the deflection mirrors. Check for corresponding accessories in the objective mounting set.




Caution!

- When installing the objective, ensure that all components of the corresponding objective mounting set are used. Failure to install included seal or space rings can lead to a mirror crash (resulting from inadequate distance between the deflection mirrors and the objective). Furthermore, the beam exit might not be optimally sealed.
- ▶ Some objectives are secured to their holders via screws (and washers). However, most objectives are directly screwed into the objective holder. Before screwing in the objective, lightly lubricate its threads (e.g. with vacuum grease) to prevent cold welding between the objective and its holder.

4.3 Layout and Dimensions

Figure 5 shows the layout of the scan head with the electrical connectors.




Scan head overview with connector position

Figure 8 shows the following distances:

- ▶ the working distance A
- ▶ the distance B between the axis of the input beam and the lower edge of the housing
- ▶ the distance C between the axis of the input beam and the lowest edge of the objective or its enclosure.
- ▶ the diameter D which is the larger of the diameters of the objective and its enclosure.
- ▶ the distance E between the front edge of the mounting bracket and the axis of the beam exiting the scan head.


Figure 6 on page 19 shows the scan head with its outer dimensions and the parts which are important for mounting. The scan head installation is described in chapter "Mounting the Scan Head", on page 22.

Figure 7 on page 20 and figure 8 on page 21 show the dimensions necessary for mounting the scan head and adjusting the scan head with respect to the working area. Figure 7 depicts the scan head's mounting surface with its mounting bore holes and a bottom view of the scan head (beam exit side) which shows the displacement of the entry beam axis from the axis of the objective or from the beam exit axis (The deflecting mirrors are in their neutral positions).




Scan head with mounting assembly (all dimensions in mm)


Mounting bracket with holes for beam-in, alignment pins and mounting screws



Bottom view and beam displacement



Scan head mounting bracket and bottom view (all dimensions in mm)



Working Distance A, distances B-E (see [chapter 4.4](#)) and dimensions (hurrySCAN[®] 10 with objective SCANLAB #100832)

4.4 Mounting the Scan Head

The illustrations for this section are found in the previous section, starting on [page 18](#).

The scan head is delivered with a mounting bracket fixed to the beam entrance side and designed for attachment to a standardized flange on the laser system – see [figure 6 on page 19](#). The laser system flange, alignment pins and mounting screws are not included in the package.

The dimensions of the mounting bracket and its bore holes are shown in [figure 7 on page 20](#). The beam entry position is defined by two 6^{H7} alignment holes on the mounting bracket. The laser beam axis must be identical with the laser input axis of the scan head. To ensure this alignment, the laser system flange must have appropriate holes to accommodate two 6_{h6} alignment pins and two M6-threaded mounting screws.

On designing the attachment flange, also consider the position of the scan head's electrical connections (see [figure 5 on page 18](#)).

Mount the scan head in the following manner:

- ▶ Carefully remove the protective covering of the laser input hole (e.g. with a small screwdriver).
- ▶ Place two 6_{h6} alignment pins in the corresponding 6^{H7} alignment holes on the flange or mounting bracket.
- ▶ Place the scan head on the flange so that the alignment pins line up with the alignment holes on the flange and the mounting bracket. This way the scan head is aligned with respect to the laser.
- ▶ Fasten the scan head to the flange by installing two mounting screws with M6 threads into the corresponding threaded mounting holes.
- ▶ On mounting the scan head consider a correct alignment in respect to the entering laser beam (also see [chapter "Adjustment and Alignment", on page 27](#)) and in respect to the working field (also see [figure 8 on page 21](#)).




Caution!

- To align and fasten the scan head, only use the alignment and mounting holes depicted in [figure 6 on page 19](#). Other holes cannot be used for aligning and fastening the scan head or for any other purposes.

4.5 Electrical Connections

Figure 5 on page 18 shows the location of the electrical connectors on the scan head.

The scan head provides a 25-pin DIGITAL IN female D-SUB connector for data transfer and a 9-pin POWER IN male D-SUB connector for power supply as well as a 15-pin Z-OUT female D-SUB-connector for connecting a Z axis. Figure 9 shows the pin assignments of the connectors.



Pin out of electrical connectors


Power Supply

Requirements

For power, the scan head requires a balanced source of $\pm(15+1.5)$ V with a maximum current of 3 A per pole. The residual ripple of the power source should not exceed 10 mV_{pp} (power sources with larger residual ripple may be applicable – after reconsulting SCANLAB – for applications which only require reduced quality).

Only use a power supply with soft start.

There should be no more than ± 5 V potential difference between the grounds of the power source and the control computer. Both the power source and the control computer should be grounded. Usually the ground of the control computer is already connected to the mains's grounding wire (PE) via the mains cable. Therefore the ground of the power source - i.e. the GND connector on the output side of your power supply - should also be connected to the mains's grounding wire (PE; see "cable 1" in figure 10). The cable connecting the GND connector with the PC ground should be as short as possible, as long connections can also produce excessive potential differences.



Connect the power supply's GND connector and the PC ground to the mains's grounding wire (PE).

Connections

The power signals should be assigned to the corresponding pins of the scan head's male POWER IN connector (+15 V / GND / -15 V, see [figure 9](#)).

- ▶ Make sure each power connection has the correct polarity.
- ▶ Connect each pole of the power source via an appropriate cable to all *three* corresponding pins of the scan head power connector as described below. The cable connecting the power supply and the scan head must be shielded and should have a cross-sectional area of at least 1.5 mm² per pole and a length not exceeding 6 meters. RFI must be minimized by connecting the cable's shielding at one end (utilizing a large surface area) to the power supply's metal shielding and at the scanhead-end to the housing's D-SUB connector.
 - connect the -15 V power source to all three -15 V pins of the POWER IN connector
 - connect the +15 V power source to all three +15 V pins of the POWER IN connector
 - connect the power source GND to all three GND pins of the POWER IN connector



Caution!

- Before proceeding with wiring the scan head, make sure none of the wires carry any voltages. The control electronics and the computer must be turned off.
- Turn off the power supply before disconnecting the power or the data cable.
- Follow all power supply electrical specifications exactly.


Data Cable Guidelines

The signals are transferred from the controller to the scan head via a data cable. This data cable should be connected to the female DIGITAL IN connector. Scan heads from SCANLAB are generally delivered without a data cable. If the data cable is not included in your package, SCANLAB recommends the following cable configuration:

- ▶ The SCANLAB data cable has identical 25-pin D-SUB connectors on both ends. The data cable is made up of up to six twisted cable pairs and connects the scan module to the controller via the SYNC±, CLOCK±, CHAN1±, CHAN2±, CHAN3± and STATUS±. CHAN3 is provided for optional control of the Z-axis. A description of these signals can be found in [chapter 2.2, "Scan Head Control"](#), on page 7.
- ▶ The data cable must have coaxial copper braided shielding.
- ▶ The cable should not be longer than 10 m. If a longer data cable is needed, the signal timing of the RTC® should be adjusted to ensure correct communication between the RTC® and the scan head. For details, see the RTC® command "set_piso_control" in the RTC® manual. The cable length must not exceed 20 m.
- ▶ The D-SUB connectors must have fully shielded metal housings.
- ▶ The electrical connection of the cable's braided shielding to the D-SUB housing should not be implemented as a wire. Instead, the cable's braided shielding should be *coaxially* connected to the D-SUB housing via shielded clamps.
- ▶ The data cable's controller end must be fitted with a ferrit ring (e.g. Würth WE 742 711 32).

[Figure 11](#) shows the data cable layout and pin assignments.

- ▶ Connect the scan head via the data cable to the customer-specific controller.
- ▶ If an RTC® board is used as the controller, then follow the installation instructions in the RTC® manual.



Data cable layout and pin assignments

4.6 Operating and Storage Conditions

For storage, operation and servicing, make sure the following environmental conditions are met:

- The storage temperature for the scan head should be between $-35\text{ }^{\circ}\text{C}$ and $+60\text{ }^{\circ}\text{C}$.
- The operating temperature is $25\text{ }^{\circ}\text{C} \pm 10\text{ }^{\circ}\text{C}$.
- Protect the scan head from humidity, dust and corrosive vapors to avoid damage to the mirrors, optics and electronics.
- Avoid strong electromagnetic fields and static electricity. These can damage the electronics of the interface and amplifier boards.

5 Start-up and Operation

5.1 Checking the Installation

Before operating the scan head, carefully check the following:

- ▶ Were the mechanical installation and electrical wiring fully and correctly carried out as described in "Installation" on page 16?
- ▶ Are all optical components clean and free of dust? If necessary, clean the optical components as described in "Routine Maintenance of the Optical Surfaces" on page 31.

5.2 Checking the Laser Parameters

The scan head's deflection mirrors and objective are designed for a laser beam with defined parameters.

- ▶ Compare the technical specifications on page 34 with the requirements of your application. For information on tolerances and deviations, please contact SCANLAB.
- ▶ Verify that the input beam wavelength, the input beam diameter and the maximum laser power are compatible with the specifications of the scan head.



Caution!

- The mirror coatings are designed for a laser wavelength of 1064 nm.
- The AR coating of the objective is designed for a laser wavelength of 1064 nm.
- The maximum allowed average laser power is 150 W. The laser power density applied to the mirrors must not exceed the value of 500 W/cm² continuous wave. The damage threshold value for pulsed operation is 5 J/cm² (for a pulse length of 10 ns and 200 pulses)
- The beam diameter at the entrance of the scan head must not exceed 10 mm.

The values specified for the maximum laser power rating and the laser damage threshold only apply to the scan mirrors. They do not apply to the scan objective or other components. Typically, however, the damage thresholds of scan objectives are similar to that of scan mirrors.

Also be aware that additional optical components in the optical beam path can focus a part of the laser beam onto the mirror and thereby dramatically lower the effective damage threshold. For instance, the lenses or protective window of a scan objective – though coated with an antireflex coating – always reflect a certain fraction of the laser light. If the lenses are shaped such that the reflected laser light is focused onto the scan mirrors, the power density

within this focus may be more than 1000 times larger than in the original beam and the effective damage threshold will be correspondingly reduced. In particular, the mirrors can be damaged by lasers with high pulse energies, short pulse lengths and good beam quality. Contamination on or damage to the optical surfaces of the objective or protective window can further increase residual reflectivity, which further increases the danger of mirror damage from back reflections.

Furthermore, the specified values only apply to clean and new mirrors. Mirror contamination (dust, fingerprints, cleaning residue, deposits from laser processing etc.) as well as mechanical damage (scratches, fractures, burn-in, damage by an improper cleaning procedure) can considerably reduce the damage threshold.

The specified damage threshold for pulsed operation is the maximum energy density for which no mirror-surface damage is expected for the specified wavelength and for two hundred 10 ns pulses onto the same mirror spot (see note below).

In general, the damage threshold considerably decreases with an increasing number of laser pulses. In continuous operation, SCANLAB therefore recommends only applying suitably reduced energy densities (depending on the repetition rate and the laser parameters, typically five times smaller than the specified pulse damage threshold, if necessary even smaller).

The damage threshold for pulsed operation also decreases with decreasing pulse length. In particular, this effect must be considered for pico- or femto-second lasers.

Note: The specified damage threshold energy density corresponds to 0% damage probability (see ISO 11254). Here, damage means a permanent, laser induced surface modification. Test parameters: angle of incidence: 45°; pulse length (FWHM): 10 ns; beam profile: TEM00; 200 pulses per test site; inspection method: Nomarski dark field microscope (150x).

5.3 Adjustment and Alignment

To ensure optimum performance of the scanning system, it is crucial that the laser beam and the scan head are precisely aligned with respect to each other. Incorrect alignment might lead to the following effects:

- vignetting of the laser beam
- a large, irregular spot
- arbitrary translation of the image field

In most cases, vignetting will be the predominant effect. Vignetting occurs if the laser beam is not able to fully pass through or be reflected by the optical components. Part of the beam's diameter will be cut off, resulting in power loss and possible system damage due to excessive absorption of laser power.

To avoid significant vignetting, the system must be aligned as precisely as possible, particularly in terms of the beam position relative to the scan head's optical axis. If the laser beam profile is Gaussian, the maximum tolerances appropriate for most applications are:

- tilt of the laser beam: < 5 mrad
- displacement: < 0.3 mm

If you use a laser with "flat top" beam profile, it can be necessary to align the system with even higher precision. Avoid vignetting especially for a high power laser. Align carefully and – if necessary – reduce the beam diameter to an appropriate value.



Danger!

- Do not stare directly into the laser beam or at any of its deflected radiation. Keep all parts of the body away from direct contact with the laser beam or any of its deflected radiation.
- Adjust the output beam path of the scan head by means of a laser with a laser class not higher than 2. If this is not possible, the laser should be operated at the lowest power. Avoid dangerous deflected radiation!



Caution!

- Remove the protective covers from the scan head's beam entrance and beam exit or objective prior to first-time operation.

In order to achieve optimal processing quality, it may be necessary to fine-tune the working distance A. The working distance A is defined as the distance between the axis of the laser beam entering the scan head and the nominal working plane – see [figure 8](#). Adjust the working distance A to the value provided in the technical specifications on [page 34](#).

The working distance A can be directly adjusted in small steps. Alternatively, the working distance A can also be adjusted indirectly via the beam divergence – this can be achieved with the help of a beam expander or a variable focusing system (for example, SCANLAB's varioSCAN 20) placed in front of the scan head's entrance aperture.

5.4 Checking the Parameters of Application Software

Before you start a laser application, you must carefully check your application software with regard to the maximum allowed scan angle and working area.

If scan angles larger than the *maximum allowed scan angle* indicated on [page 34](#) are used, some vignetting inside the scan head can occur and damage to the interior of the scan head and the objective might result. If your application requires larger scan angles and a larger image field, then contact SCANLAB for guidance.

5.5 Safe Start-up and Shutdown Sequences

To assure safety during start-up, proceed exactly as follows:

- (1) Turn on the controlling PC containing the RTC[®] PC interface board and start up the control software (or alternatively switch on the RTC[®] SCANalone standalone board).
- (2) Turn on the power supply for the scan head.
- (3) Turn on the laser.

When shutting down the system, turn off the components exactly in reverse order.



Caution!

- Before first-time operation, check the polarities of the power supply connections for the scan head.
- Always turn on the control (PC) and the power supply for the scan head prior to turning on the laser. Otherwise there is the risk that the laser beam might be deflected in an arbitrary direction.
- Power for the scan head must be applied only when the control (PC, RTC[®] and control software) are active.

6 Optimizing the Application

6.1 Dynamic Positioning with Galvanometer Scanners

SCANLAB's galvanometer scanners and amplifier boards allow precise dynamic control of the two deflection mirrors. This enables exact positioning of the laser beam with high speed.

Most laser applications require the laser focus to trace contours within the working plane at a constant processing speed. To achieve this, the control subdivides the contours into microsteps. Microstep length is determined by the output period and desired speed. Galvo dynamics are usually optimized for such microvector control. For ensuring optimum operation, the following properties of galvanometer scanners must be considered:

Positioning Speed

As galvo dynamics are usually optimized for microvector control, it is advisable to also use vectors when positioning with the laser switched off. Compared to hard jumps, a defined positioning speed will prevent excessive oscillation and usually produce shorter positioning times. Positioning speeds can generally be significantly higher than processing speeds.

A typical and a maximum positioning speed (in [rad/s]) each is listed in "Technical Specifications" on page 34. There, the typical positioning speed is also specified (for a selected F-Theta objective) as positioning speed within the image field (in [m/s]).

With the SCANLAB RTC[®] PC interface board or the RTC[®] SCANalone standalone board, the positioning speed (jump speed) can be set via the **set_jump_speed** software command. The RTC[®] jump speed (in [bit/s]) is derived by multiplying the positioning speed (in [mm/s]) by the correction file's calibration factor (in [bit/mm]). With vector tuning, the jumps themselves should be executed via the commands **jump_abs** or **jump_rel**.

Processing Speed

The processing speed must be adjusted according to the particular application. As an example, a typical marking speed for marking small characters (marking speed in the image field in [m/s] for a selected F-Theta

objective) is specified in "Technical Specifications" on page 34. For other applications or optical configurations, the appropriate processing speed can differ considerably from the specified value.

An appropriate initial value for optimizing the positioning speed is the marking speed listed in "Technical Specifications" on page 34. The process speed (RTC[®] mark speed) that can be set via an RTC[®] board is specified by multiplying by the correction file's calibration factor (in [bit/mm]).

Tracking Error (Time Lag)

Galvanometer scanner movements do not occur instantaneously with respect to vector control, but rather after a certain time lag, the tracking error. The tracking error characterizes the reaction properties of the galvanometer scanners and is specified as another key dynamic parameter (see "Technical Specifications" on page 34). The vector control output period must be significantly shorter than the tracking error. Otherwise, instead of moving the galvos with constant speed, the servos would attempt to follow the individual microsteps. This, in turn, would increase power consumption and thermally stress the galvos. SCANLAB therefore recommends as short an output period as possible, no more than 20% of the tracking error. SCANLAB's RTC[®] boards consistently achieve very good results with an output period of 10 μ s.

Oscillation behavior and tracking error must be taken into account by the application software, which synchronizes the scan head and the laser control. If the scan head is controlled via a SCANLAB RTC[®] PC interface board or via an RTC[®] SCANalone standalone board, then synchronization is easily realized by appropriately setting the scanner and laser delay parameters. SCANLAB recommends the following as initial values for delays:

- Laser-On Delay: 60% of the tracking error
- Laser-Off Delay: 120% of the tracking error
- Jump Delay: 200% of the tracking error
- Mark Delay: 100% of the tracking error
- Polygon Delay: 50% of the tracking error

The RTC[®] user manual describes how delays can be optimized for an application's quality requirements.

6.2 Optimum Environmental Conditions and Automatic Self-Calibration

Long-term repeatability is very important in many scan head applications, e.g. for rapid prototyping in which the processing operation can span several hours. For such laser applications, the long-term drift and temperature drift of the scan head's galvanometer scanners, which manifest as a shift (offset drift) and increase or decrease in the size (gain drift) of the working image field, can exceed the allowable tolerances.

In such applications, it's helpful to start up the application only after the scanners have reached their operating temperature. In addition, the magnitudes of environmental fluctuations (e.g. operating temperature changes to which the scan head is exposed) should be kept as small as possible and the scan head preferably operated with a constant load.

For higher long-term repeatability requirements, SCANLAB scan heads can be (optionally for apertures ≥ 10 mm) equipped with an additional internal sensor system for automatic self-calibration. This reference system provides the RTC[®] software with the ability to automatically calibrate the galvanometer scanner position detectors at any desired time.

During calibration, the scan head automatically seeks several reference positions within the scannable area that are defined by the internal sensor system. The seek values are determined and compared with fixed reference values. From the resulting deviations, offset and gain compensation factors are calculated. These compensation factors are immediately made available for use in all future positioning tasks.

The calibration routine can be initiated via a simple RTC[®] command (please refer to the RTC[®] manual for details). The laser should be switched off during the calibration procedure and no other commands are transferred to the scan head until the calibration is completed. The entire calibration procedure takes place in about 5 seconds.

Thus, the effects of gain and offset drift can be reliably compensated and positioning accuracy is maintainable over long periods of time. Remaining long-term drift effects are the same order of magnitude as short-term repeatability.

6.3 Process Monitoring

The scan head provides internal protective mechanisms for monitoring

- the operating temperature

(also see [chapter 2.3, "Internal Protective Functions", on page 11](#)).

In addition, the user has various possibilities for monitoring the scan process as described in the following.

Software Monitoring

For monitoring via software the scan head provides a status signal with informations about the current scan head operational state.

Optical Process Monitoring

For camera-based observation of the scan head's working field SCANLAB offers a camera adapter. The camera adapter can be mounted between the scan head's beam entrance and the laser flange. Then the camera adapter's dichroitic beam splitter decouples light reflected from the illuminated workpiece and arriving the scan head's beam entrance via the scan objective and the scan mirrors. The light is decoupled from the beam path and then directed to the camera. Please contact SCANLAB for further information (see [page 32](#)).

7 Routine Maintenance and Customer Service

7.1 Routine Maintenance of the Optical Surfaces

Dirty objectives and mirrors increase the absorption of laser power by their respective optical surfaces. Dirt, dust and other contaminants can distort the laser beam, burn into the surface and damage the optical elements. The warranty does not cover any damage due to improper use, cleaning or handling.

Routine Maintenance of the Mirrors

The deflection mirrors are especially sensitive components and should not be touched or removed from the scan head. Nevertheless, you must regularly inspect the mirrors for dirt, dust and other contaminants. The mirrors must also be inspected after a long storage time.

If inspection reveals dust particles, then remove them by blowing air on the mirror's surface with the help of a rubber squeeze bulb or a source of compressed clean air.

If the dust cannot be removed in this manner, or if inspection reveals more serious contamination, then contact SCANLAB for guidance. In extreme cases, the complete scan head must be returned to SCANLAB for inspection and cleaning of the mirrors. However, in some situations SCANLAB might be able to recommend a user-performed special cleaning procedure.

Routine Maintenance of the Objective's Optical Surface

The outermost optical surface of the scan head's objective is cleanable by the user. Regularly check the scan head's objective. If dirt, dust or other contaminants are found, clean the objective's optical surface as follows:

- ▶ Using a rubber squeeze bulb or compressed clean air, blow air on the objective's surface to remove dust and dirt particles. If the objective is still not clean, then use solvent and lens cleaning tissues as described below:

Cleaning Notes

- Avoid skin contact with the optic.
- Use only clean lint-free tissues specially manufactured for cleaning optics (e.g. "Kodak lens cleaning paper"). Always use lens tissues with a solvent, because dry tissue can scratch optical surfaces.
- Use a solvent such as acetone or isopropanol of high purity (evaporation residue < 0.001%). Read and follow the safety advice and warnings for the solvents you will be using.
- Use clean gloves or finger cots that are impermeable to the organic cleaning solvents you will be using.
- Always wipe slowly but steadily, using a circular motion from the center of the optic around to the outer edges. Do not rub back and forth!
- Only wipe with slight pressure!

- (1) Create a lens-tissue brush by folding a clean lens tissue so that the fold is about half as wide as the objective's lens surface.
- (2) Dampen the lens-tissue brush with solvent. Don't use too much solvent, because otherwise drying marks might appear.
- (3) Carefully grip one end of the dampened lens-tissue brush without touching any part of the tissue that will touch the lens surface.
- (4) Place the dampened lens-tissue brush in the center of the objective's lens surface. Then use a *circular* motion to wipe slowly but steadily from the center of the optic around to the outer edges.

Repeat the above procedure until the objective's optical surface is completely clean. For each cleaning swipe, create a new lens-tissue brush.



Danger!

- Never stare at the laser beam or its deflected radiation when performing routine maintenance of the scan head. Keep all parts of the body away from direct laser beams or deflected radiation. When the laser beam is not required, turn it off or reliably block it via a shutter to prevent its entry into the scan head.

7.2 Customer Service

Servicing and Repairs

Except for routine maintenance of the optical surfaces, the scan head does not contain user-serviceable internal parts. All servicing and repairs should be performed only at SCANLAB. Only SCANLAB has the proper test facilities and procedures to service, repair and calibrate the system optimally.

Product Warranty

SCANLAB guarantees this product to be free of defects in manufacturing and material. The warranty is valid for 12 months after delivery. Repairs covered under the warranty will be performed at SCANLAB.

The scope of the warranty is limited to repair or replacement of the SCANLAB product.

SCANLAB is responsible for the return delivery of products repaired under warranty; the customer is responsible for delivery to SCANLAB.

SCANLAB will not be held responsible:

- when the product has been damaged through misuse or improper operation
- for damage due to improper laser power (e.g. focused beam on optical surfaces) or improper adjustment
- for damage to optical components (mirrors, objective, etc.) caused by improper handling or cleaning
- for consequential damages
- if the scan head has been altered
- if the warranty seal on the scan head's housing has been broken

If a returned scan head must first be brought into a serviceable state by SCANLAB (e.g. by removing alignment pins and other customer-added parts or cleaning the scan head) before servicing can begin, then the customer must bear the additional cost.

Contacting SCANLAB

For service, repairs, advice or information, simply contact SCANLAB using one of the contact possibilities listed below:

SCANLAB AG
Siemensstr. 2a
82178 Puchheim
Germany

Tel. +49 (89) 800 746-0
Fax: +49 (89) 800 746-199

info@scanlab.de
www.scanlab.de

Product Disposal

The hurrySCAN® 10 can be returned to SCANLAB for a fee to be properly disposed of in compliance with environmental regulations.

8 Troubleshooting

If problems occur while operating this device, verify that all operating instructions have been adhered to and then carry out the following troubleshooting procedures:

Problem	Possible Cause	Remedy
Low laser power	Dirty objective	Clean as described in " Routine Maintenance of the Optical Surfaces " on page 31
	Altered controller software parameters	Check input parameters
	Dirty or damaged mirror	Check mirrors. If they are contaminated, call SCANLAB for guidance. Return damaged scan head mirrors for repair.
Changed laser spot	Dirty or damaged objective	Clean as described in " Routine Maintenance of the Optical Surfaces " on page 31
	Dirty or damaged mirror	Check mirrors. If they are contaminated, call SCANLAB for guidance. Return damaged scan head mirrors for repair.
	Laser out of adjustment	Adjust laser
No laser beam	Problem with the laser	Check laser and electrical connections
	Problem with the laser controller	If the RTC [®] board is used, check all electrical connections and the power supply
	Laser beam path blocked or shutter closed	Check laser beam path
Scan head does not steer laser beam in one or both directions	Problem with the scan head controller	Check power and data cables. Check software commands.

If the problems persist, please send the scan head to [customer service](#).

9 hurrySCAN® 10 Technical Specifications

(all angle specifications optical)

SCANLAB ID numbers

of scan head	112466
of objective	100832

Aperture

maximum diameter of the laser beam inside the scan head 10 mm

Control

Input and Output Signals	XY2-100 Standard
Maximum range for control values ⁽¹⁾	0 to 65535
Calibration	±0.408 rad with (32768 ± 31457) Bit

Maximum allowed scan angle (vignetting insignificant) ⁽²⁾

- without objective	±0.36 rad
- with objective 100832	±0.34 rad

Power supply

Requirements	±(15+1.5) V DC, max. 3 A each pole
--------------	---------------------------------------

Optical Performance

Gain error	< 5 mrad
Zero offset	< 5 mrad
Skew	< 1.5 mrad
Nonlinearity	< 3.5 mrad
Repeatability	< 22 µrad
Long-term drift over 8 hours (after warm-up)	< 0.6 mrad

(1) This maximum range for input values should be regarded as a theoretical range. Due to the danger of vignetting by the mirrors or by the objective (also see [page 6](#)), the specified maximum scan angle must never be exceeded.

(2) Theoretical value (see [page 6](#) and [page 8](#))

(3) See [page 29](#).

Tuning Specifications (Dynamic Performance) ⁽³⁾

Tracking error	< 0.18 ms
Typical positioning speed (* with 160 mm objective)	45 rad/s (*7 m/s)
Maximum positioning speed	100 rad/s
Typical marking speed (for marking small characters, with 160 mm objective)	2 m/s
Step response (settling to 1/1000 full scale)	<ul style="list-style-type: none"> • 1% of full scale 0.35 ms • 10% of full scale 0.90 ms

Objective and image field

Wavelength, for which the following specifications were calculated	1064 nm
Focal length f (nominal)	254 mm
Typical image field	(170 x 170) mm ²
Working distance A (see figure 8 on page 21)	390 mm

Mirror

Coating	dielectrical high performance coating
Working wavelength	1064 nm
Reflectivity	<ul style="list-style-type: none"> - at 1064 nm more than 99.5% per mirror, over the full range of angles - at 630 nm to 670 nm more than 70% per mirror

Maximum allowed average laser power 150 W

Maximum allowed laser power density continuous wave 500 W/cm²

Damage threshold for pulsed operation (with specified working wavelength, pulse length 10 ns, 200 on 1, also see [page 27](#)) 5 J/cm²

Weight

without objective 2.7 kg

Operating and Storage Conditions

Operating temperature 25 °C ± 10 °C
 Storage temperature –35 °C to +60 °C
 Environmental conditions non-condensing,
 non-corrosive

9.1 Electromagnetic Compatibility

Compliance with EC Guidelines for Electromagnetic Compatibility (EMC)

The SCANgine[®], hurrySCAN[®] II, hurrySCAN[®] 10/14, SCANjet[®] II and SCANjet[®] series of scan heads have been determined to be in compliance with EC-Guidelines 89/336/EEC (electromagnetic compatibility).

For that purpose, a scan head from one of the above-mentioned series was tested in the following configuration:

- hurrySCAN[®] II 10, digital
- RTC[®] 4 PC interface board

Test Specifications

Evidence of fulfillment of the protection goals of the July 1993 version of EC Guidelines 89/336/EEC (CE Conformity for EMC) based on

- EN 61000-6-2: 2001
- EN 61000-6-4: 2001

Result

The device under test fulfills the specifications.

Index

A

adjustment and alignment of scan head	27
alignment holes	22
alignment pins	19, 22
aperture	6, 26, 34
application	
optimizing	29
application software	
checking parameters of	28
article number	1, 5, 34
assembling the scan head	16–22
automatic self-calibration	30

B

beam diameter	6, 26
beam displacement	18, 20
beam entrance	18
beam entrance / exit	
protective cover	28
beam vignetting	6
bottom view of scan head	20

C

calibration	
automatic	30
specifications of scan head	34
camera adapter	30
CE label	12
checking	
application software parameters	28
installation	26
laser parameters	26
specifications of scan head and application .	16
cleaning notes	31
cleaning optical surfaces	31
clock signal	7
coatings, optical	6, 34
configuration, optical	6
connections	
power supply	24
connector	
DIGITAL IN	23
pin outs	23
position on scan head	18
POWER IN	23
Z-OUT	23
contacting SCANLAB	32
contents of package	5
control	7
input values	34
signals	8
correction table	8

critical temperature shutdown	11
customer service	32

D

damage threshold	6, 26, 34
data cable	24
data transmission	7
deflection mirrors	6, 13, 29, 31, 33, 34
DIGITAL IN connector	23
dimensions of scan head	18
displacement, of laser beam	27
disposal of scan head	32
distances	
various defined	18, 21
working A	18, 21
drift	
gain	30
long-term	34
offset	30
dynamic performance	34

E

electrical connections	23, 34
electrical safety	15
electromagnetic compatibility	12, 35
environmental conditions	25, 35
optimum	30

F

field distortion	8
flange, laser system	19, 22
focal length	34

G

gain drift	30
gain error	34
galvanometer scanners	
behavior of	29
lag time	29
guarantee	32
guidelines	
electromagnetic compatibility	12
for data cable	24

I

ID number	1, 5, 34
ID plate	5

image field	8	N	
distance to beam entrance	21	nonlinearity	34
distortion	8	O	
size	9, 34	objective	6
specifications	34	holder	16
square	9	inspecting and cleaning	17, 31
input signals	8, 34	installing	16
installation	16–25	mounting set	16
checking	26	protective cover	28
of objective	16	SCANLAB-ID#	1, 5, 34
interface	7	specifications	34
specifications	34	offset drift	30
interference immunity	12, 35	operating and storage conditions	25
internal protective functions	11	operating manual, about this	5
L		operating safety	12
lag time of scanners	29	operating temperature	35
laser beam		operation and start-up	26
diameter	34	optical configuration	6
displacement of	27	optical performance	34
tilt of	27	optics	
vignetting	6	inspecting and cleaning	31
wavelength	26, 34	specifications	34
laser parameters, checking	26	optimizing the application	29
laser power density, maximum	26, 34	optimum environmental conditions	30
laser power, maximum	26, 34	output signals	34
laser radiation		overview	18
classes of	14	overview of product	5
warning symbols	13–15	P	
laser rating	6, 26, 34	package contents	5
laser safety	13–15	performance specifications	
laser system flange	19, 22	optical	34
layout of scan head	18	pillow-barrel distortion	8
long-term drift	34	pin outs of connectors	23
M		PosAck signal	10
maintaining optical surfaces	31	position signals	8
manual, about this	5	positioning laser beams	6
manufacturer, contact	32	positioning speed	11, 29, 34
marking speed	34	POWER IN connector	23
maximum scan angle	7	power supply	
mirrors	6, 13, 29, 33, 34	connections	24
coatings	6, 34	maximum cable length	24
inspection of	31	requirements	23, 34
wavelength	6, 34	principle of operation	6
monitoring		process monitoring	30
the operating temperature	11	processing field	8
via camera	30	processing speed	29
via software	30	product disposal	32
mounting		product overview	5
parts for scan head mounting	19	protective covers	28
screws	22	protective functions	11
the objective	16	PWROK signal	9, 11
the scan head	22		
mounting bore holes	20		
mounting bracket	19, 20		

R		
reference system	8	
repairs	32	
repeatability	30, 34	
routine maintenance	31	
S		
safe operating temperatures	11	
safety		
during installation and operation	12	
EC guidelines	12	
electrical safety	15	
electromagnetic compatibility	12, 35	
laser radiation warning symbols	13–15	
laser safety	13–15	
operating safety	12	
safety and warning symbols in manual	12	
standards and guidelines	12	
scan angle, maximum	7, 34	
scan head		
adjustment and alignment of	27	
control	7	
control values	34	
mounting onto laser system	22	
optics, checking and cleaning	31	
repairs	32	
servicing	32	
technical specifications	34	
SCANLAB, contacting	32	
scanners		
characteristic behavior	29	
lag time	29	
screws, mounting	19	
self-calibration	30	
serial number	5	
servicing	32	
shutdown sequence	28	
shutter	13	
signal transmission	7	
signals	34	
input	8	
PosAck	10	
PWROK	9	
status	9	
synchronization	7	
TempOK	9	
skew, error	34	
specifications, technical	34	
start-up	26–28	
and operation	26	
and shutdown sequences	28	
status signals	9	
step response	34	
storage and operating conditions	25	
storage temperature	35	
suppression of radio interference	12, 35	
		synchronization signals
		7
		T
		technical specifications
		34
		temperature
		11
		critical shutdown
		11
		safe operating
		11
		status warning
		11
		status warning TempOK
		11
		TempOK
		11
		TempOK signal
		9, 11
		tilt, of laser beam
		27
		time lag of scanners
		29
		tracking error
		29, 34
		troubleshooting
		33
		tuning
		specifications
		34
		typical positioning speed
		34
		U
		unpacking instructions
		5
		V
		varioSCAN
		6
		vector rate
		11
		vignetting, beam
		6, 27
		W
		warranty
		32
		wavelength
		6, 26, 34
		objective
		34
		weight
		35
		working distance A
		18, 21, 28, 34
		working field
		8
		X
		X-Y reference system
		8
		XY2-100 standard
		7
		Z
		zero offset
		34
		Z-OUT connector
		23



Notes