

# Getting Started: Running the ZigBee™ -2006 Demo

[INTRODUCTION](#)

[REQUIRED HARDWARE](#)

[CONFIGURING THE HARDWARE](#)

[FIRMWARE](#)

[RUNNING THE APPLICATION USING PUSHBUTTONS](#)

[RUNNING THE APPLICATIONS via the HYPER-TERMINAL CONSOLE](#)

[FAQs](#)

[TRADEMARKS](#)

## INTRODUCTION

The Microchip ZigBee 2006 Residential protocol stack, version v2.0-2.x, provides wireless connectivity based on the standards set by the ZigBee Alliance. The ZigBee standard uses the IEEE 802.15.4 for the Physical and MAC layer definitions. The remaining layers are defined by the ZigBee Alliance. Customization on the Application Layer allows users to develop a wide range of applications based on the ZigBee protocol.

The application that is included as part of version v2.0-2.x of the Stack, demonstrates several network connectivity features. These features include:

- The ability to enable or disable devices from joining other devices that are on a network. This feature is useful in assisting the configuration of a specific network topology when first forming a network.
- The capability for sending data to, or requesting data from, a specific device – unicast addressing, and sending to, or requesting from all the devices in the network – broadcast addressing.
- Multicasting – The capability for sending data to, or requesting from, devices that are members of a specific group. A group ID is used to reference the devices that are part of a given group.
- The capability for adding or removing a device from membership in a Group. Later in this Guide, instructions are provided on how to add and/or remove a device to and/or from groups.
- The ability to display the Neighbor Table information for each device.

All of the above features are available to the user via the Stack Application's menu driven system.

The following features are available via two Push Buttons on both the PICDEM Z and Explorer 16 platforms:

- Multicasting – Sending data to, or requesting from, devices that are members of Group 0x0004.
- Adding or removing a device from membership in Group 0x0004.

Group 0x0004 is hard coded in the current push button application in order to simplify the code and to illustrate the Multicasting feature as simply as possible. However, from the menu driven application, the user has the option of choosing Group IDs within the range of 0x0001 to 0x00f0.

Individual nodes can include themselves as a member of a Group by creating and maintaining a Group Table. The Group Table contains both the Group ID and associated Endpoints of the group(s) to which the node is a member of.

## REQUIRED HARDWARE

In order to set up a simple network consisting of two nodes, two hardware platforms chosen from any of the two configurations is required.

### Hardware Platform Set 1 (8-bit platform)

- PICDEM Z 2.4 Demo Kit ([DM163027-4](#) OR [DM163027-5](#))
- [PICDEM Z MRF24J40 2.4GHz Daughter Card](#) (AC163027-4)  
OR
- [MRF24J40MA PICDEM™ Z 2.4GHz RF Card](#) (AC163028)

### Hardware Platform Set 2 (16-bit platform)

- [Explorer 16](#) (DM240001)
- [PIC24FJ128GA010 Plug-In-Module \(PIM\)](#) (MA240011)
- [PICDEM Z MRF24J40 2.4GHz Daughter Card](#) (AC163027-4)  
OR
- [MRF24J40MA PICtail™ Plus 2.4GHz RF Card](#) (AC164134)

### Miscellaneous Hardware

- At least one RS-232 Serial Cable
- Personal Computer with RS-232 COM port or USB to RS232 adapter

### Environment


- MPLAB C18 compiler v3.20 or higher for the PICDEM Z PIC18F Platform
- MPLAB C30 compiler v3.10 or higher for PIC24F Explorer 16 Platform
- MPLAB IDE v8.10 or later
- A programmer such as MPLAB REAL ICE or ICD 2,

## CONFIGURING THE HARDWARE

This section describes how to set up the various configurations of hardware to run this demo.


### **Configuration 1: PICDEM Z**

1. Connect the MRF24J40 2.4GHz RF Card to the PICDEM Z demo board as shown below.




## Configuration 2: Explorer 16


1. Before attaching the PIM to the Explorer 16 board, insure that the processor selector switch (S2) is in the “PIM” position as seen in the image below.



2. Short the J7 jumper to the “PIC24” setting




3. Before connecting the PIM to the Explorer 16 board, remove all attached cables from both boards. Connect the PIM to the Explorer 16 board. Be careful when connecting the boards to insure that no pins are bent or damaged during the process. Also insure that the PIM is not shifted in any direction and that all of the headers are properly aligned.
4. Connect the MRF24J40 2.4GHz Daughter Card or MRF24J40MA PICTail™ Plus 2.4GHz RF Card to the first slot of edge card connector.



## FIRMWARE

The entire source code for the ZigBee2006 Stack is included as part of the release. The picture below depicts the directory structure for the code. The ZigBee device types – Coordinator, Router and Reduce Function End Device (RFD) are included as part of the application. A separate project file is provided for each device type such that each device can be built and be customized for specific operations. The code is suitable for development on both the PICDEM Z and the Explorer 16 platforms.



In the application provided:

**Push Button RB4/RD6** is used to add or remove the node from group 0x0004

**Push Button RB5/RD7** is used to send a group broadcast message to any device that is a member of group 0x0004. The group broadcast message requests each of the devices in the group to send back ten bytes of the data to the requester. The data that is returned to the requester will be the byte pattern [00 01 02 03 04 05 06 07 08 09 0A].

**LED RA0/D10** is turned ON whenever the device is a member Group 4; and turned OFF otherwise.

**LED RA1/D09** is used as a toggle on/off indicator. It indicates that the node has received and responded to messages addressed to it whenever it is a member of the Group 0x0004. Therefore, whenever a node is a member of Group 0x0004

and it receives a request from another device to send data, after it sends the data it will toggle this LED. This is a useful and simple way to visually ascertain that the communication link between devices is working.

When the node is connected to a hyper terminal console, then the contents of the received messages are displayed whenever the node is a member of Group 0x0004.

**Note:** There may be a slight inconsistency in the feel of the pushbuttons from device to device, so please press and release the buttons firmly, to get a consistent result across all the devices.

In order to run the sample demo applications that are included in version v2.0-2.x of the ZigBee Stack, the appropriate software must be downloaded onto the hardware platform. The Coordinator and the Router and/or RFD devices must be programmed with the proper device type selected in MPLAB. There two are two methods available for downloading the demo applications: Using the Precompiled Demo Applications and building the source code from the projects that are provided.

### ***Using the Precompiled Demo Applications***

The Precompiled Demo Applications are available at the following location:

“<Install Directory>\ZigBee2006Res\ DemoPIC24FCoordinator \DemoPIC24FCoordinator.hex”

“<Install Directory>\ZigBee2006Res\ DemoPIC24FRouter\DemoPIC24FRouter.hex”

“<Install Directory>\ZigBee2006Res\ DemoPIC24FRFD \DemoPIC24FRFD.hex”

There are similar sub-directories of the PIC18 platform as well.

Use the *File* → *Import* menu from MPLAB® IDE to import the .hex file and then use the MPLAB® Programmer to program the demo applications, first into the Coordinator and then either to the Router or RFD device.



This guide explains the Zigbee communication between the Coordinator and the Router.

### ***Building the Demo Applications***

The source code for this demo applications are available in the following folders:

**“<Install Directory>\ZigBee2006Res\DemoPIC24FCoordinator”**

**“<Install Directory>\ZigBee2006Res\DemoPIC24FRouter”**

**“<Install Directory>\ZigBee2006Res\DemoPIC24FRFD”**

In these directories, you will find all of the application level source and header files as well as the project and workspace files for each of the hardware platforms.

Double click on the **.mcw** workspace files in the appropriate folders to launch MPLAB® IDE. After selecting the appropriate programmer that is to be used, select the Project > *Build-All* option to build. Program the created firmware to the devices.


For those who are not familiar with using MPLAB IDE, the following link to the MPLAB User’s Guide will provide the help needed to set up the environment.

The guide can be found at <http://www.microchip.com/mplab>

## RUNNING THE APPLICATION USING PUSHBUTTONS

You will need:

- A pair of PICDEM Z and/or Explorer 16 devices, which are loaded with the correct demo application. One of the devices must be a Coordinator. The other device can be either a Router or a RFD.
1. Plug in the ZENA Network analyzer into the personal computer's USB port and configure it to monitor network traffic on channel 26.
  2. Apply power to the Coordinator device with a 9V wall adapter or 9V battery. Press and release the pushbutton labeled MCLR. The two LEDs labeled **RA0/D10** and **RA1/D09** will be turned ON, indicating that the device has formed a network. Observe the Beacon Request Packet on Zena. The Coordinator is now ready to accept other devices on its network.



The screenshot shows the ZENA(TM) Packet Sniffer interface for ZigBee(TM) 2006 Protocol. The main window displays a packet capture table with the following data:

Beacon Request		FCS	
RSSI	Corr	CRC	
-08	0x6B	OK	

SuperFrame Specification				GTS Specification		PndAddr Spec			Beacon Payload						
BD	SD	CAF	Batt	Coord	Assoc	Permit	Count	ExtAddr	ShortAddr	DevCap	Depth	RtxCap	NRKVer	StkProf	ProtID
None	None	0xF	H	Y	Y	N	0x0	0x0	0x0	Y	0x0	Y	0x2	0x1	0x00 0x0

3. Apply power to the Router device with a 9V wall adapter or 9V battery. Press and release its MCLR pushbutton. Two LEDs labeled **RA0/D10** and **RA1/D09** will be turned ON, indicating that the device has joined the network. Observe on Zena the Association Request packet from the Router and the successful Association Response packet from the Coordinator. The Router has now successfully joined the network.

ZENA(TM) Packet Sniffer - ZigBee(TM) 2006 Protocol																				
MAC Frame Control		Seq Num	Source PAN	Source Addr	SuperFrame Specification				GTS Specification		PendAddr Spec		Dev							
Type	Sec	Pend	ACK	IPAN	BO	SO	C&P	Batt	Coord	Assoc	Permit	Count	ExtAddr	ShortAddr	Dev					
BCN	N	N	N	N	0x10	0x1AAA	0x0000	None	None	0xF	N	Y	Y	N	0x0	0x0	Y			
MAC Frame Control		Seq Num	Source PAN	Source Addr	SuperFrame Specification				GTS Specification		PendAddr Spec		Dev							
Type	Sec	Pend	ACK	IPAN	BO	SO	C&P	Batt	Coord	Assoc	Permit	Count	ExtAddr	ShortAddr	Dev					
BCN	N	N	N	N	0x99	0x276C	0x0000	None	None	0xF	N	Y	Y	N	0x0	0x0	Y			
MAC Frame Control		Seq Num	Dest PAN	Dest Addr	Source PAN	Source Address			Association Request					RSSI						
Type	Sec	Pend	ACK	IPAN	RSSI	Corr	CRC	Alloc	Sec	RxOn	Power	Dev	AltCoord	RSSI						
CHD	N	N	Y	N	0xC7	0x276C	0x0000	0xFFFF	0x00000000	200000000	Y	Y	On	Mains	FFD	N	-06			
MAC Frame Control		Seq Num	FCS																	
Type	Sec	Pend	ACK	IPAN	RSSI	Corr	CRC													
ACK	N	N	N	N	0xC7	-10	0x68	OK												
MAC Frame Control		Seq Num	Dest PAN	Dest Addr	Source Address			Data Request	FCS											
Type	Sec	Pend	ACK	IPAN	RSSI	Corr	CRC	Status	Address	RSSI	Corr	CRC								
CHD	N	N	Y	Y	0xC8	0x276C	0x0000	0x00000000	200000000	-04	0x68	OK								
MAC Frame Control		Seq Num	FCS																	
Type	Sec	Pend	ACK	IPAN	RSSI	Corr	CRC													
ACK	N	Y	N	N	0xC8	-09	0x6B	OK												
MAC Frame Control		Seq Num	Dest PAN	Destination Address	Source Address			Association Response			FCS									
Type	Sec	Pend	ACK	IPAN	RSSI	Corr	CRC	Status	Address	RSSI	Corr	CRC								
CHD	N	N	Y	Y	0x98	0x276C	0x00000000	200000000	0xAAAAAAAAAAAAAAAA	Success	0x0001	-08	0x6B	OK						
MAC Frame Control		Seq Num	FCS																	
Type	Sec	Pend	ACK	IPAN	RSSI	Corr	CRC													
ACK	N	N	N	N	0x98	-06	0x69	OK												

Both Devices are up and running but neither is yet a member of the Group 0x0004. When a router receives a group broadcast message, first, it rebroadcasts this message so that other nodes in the network can receive the broadcast message. Secondly, it also checks if one of its endpoints is in the same group and if so, it responds to the broadcast request by responding. As none of the nodes are in any specific group at reset, if Coordinator sends messages to Group 0x0004 the Router will only rebroadcast these messages, but it will not respond with the requested 10 bytes that the Coordinator asks for.

- On the Coordinator, press and release the button labeled RB5/RD7. Observe the traffic on Zena. The messages will be broadcast messages with destination address 0xffff; Source Address 0x0000(from the Coordinator), and a tag that labels the messages as group addressed broadcast messages. The Router will rebroadcast the messages but does not respond to the Coordinator, since it is not yet a member of Group 0x0004.

Now add the Router to Group 0x0004 by doing the following:

- Press and release the RB4/RD6 button on the Router device and observe the RA0/D10 LED toggling on and off as RB4/RD6 is pressed and released. Press and release the RB4/RD6 push button such that RA0/D10 remains ON after the button is released. When RA0/D10 is ON, this indicates that the Router has added itself as a member of Group 0x0004. There is no associated traffic on Zena since this is an internal operation and nothing is transmitted over the air.
- Press and release RB5/RD7 on the Coordinator. This will send a group broadcast message to all nodes that are in Group 0x0004.

Observe that the message is broadcast to destination address 0xFFFF, Group Address 0x0004 on Zena.

Observe that the RA1/D09 LED on the Router toggles on/off each time RB5/RD7 on the Coordinator is pressed. This indicates that the Router is now responding to messages sent from the Coordinator to Group 0x0004 because it is now a member of that group.

ZENa(TM) Packet Sniffer - ZigBee(TM) 2006 Protocol																							
1	CHD	0x2	SUP	N	0xFFFC	0x0001	0x0A	0x03	Route Request				FCS										
Type	Ver	Route	Sec	Dest Addr	Source Addr	Radius	Seq Num	Opt	ID	DestAddr	Cost	RSSI	Corr	CRC									
0	CHD	0x2	SUP	N	0x0001	0x0000	0x0A	0x25	0x00	0x40	0x0000	0x00	-02	0x68 OK									
0	CHD	0x2	SUP	N	0x0001	0x0000	0x0A	0x25	0x00	0x40	0x0001	0x0000	0x01	-07 0x68 OK									
00	DAT	0x2	SUP	N	0xFFFF	0x0000	0x0A	0x26	APS Frame Control				Group Address	Cluster ID	Profile ID	Source EP	APS Counter	AF Data	FCS				
Type	Ver	Route	Sec	Dest Addr	Source Addr	Radius	Seq Num	Type	Deliv	Mode	Sec	ACK	Address	ID	ID	EP	Counter	0x0A	RSSI	Corr	CRC		
00	DAT	0x2	SUP	N	0xFFFF	0x0000	0x0A	0x26	DAT	GRP	N/A	N	0x0004	0x001C	0x7F01	0x04	0x01	0x0A	-05	0x6A	OK		
01	DAT	0x2	EN	N	0x0000	0x0001	0x0A	0x03	APS Frame Control				Dest EP	Cluster ID	Profile ID	Source EP	APS Counter	AF Data					
Type	Ver	Route	Sec	Dest Addr	Source Addr	Radius	Seq Num	Type	Deliv	Mode	Sec	ACK	Address	ID	ID	EP	Counter	0x0A	0x00	0x00	0x01	0x02	0x03
01	DAT	0x2	EN	N	0x0000	0x0001	0x0A	0x03	DAT	UNI	N/A	N	0x04	0x0054	0x7F01	0x04	0x02	0x0A	0x05	0x06	0x07	0x08	0x09
01	DAT	0x2	SUP	N	0xFFFF	0x0000	0x0A	0x26	APS Frame Control				Group Address	Cluster ID	Profile ID	Source EP	APS Counter	AF Data	FCS				
Type	Ver	Route	Sec	Dest Addr	Source Addr	Radius	Seq Num	Type	Deliv	Mode	Sec	ACK	Address	ID	ID	EP	Counter	0x0A	RSSI	Corr	CRC		
01	DAT	0x2	SUP	N	0xFFFF	0x0000	0x0A	0x26	DAT	GRP	N/A	N	0x0004	0x001C	0x7F01	0x04	0x01	0x0A	-08	0x69	OK		

- Press and release the RB4/RD6 button on the Router once again until its RA0/D10 LED is turned off. This indicates that the Router has removed itself from Group 0x0004. Further messages to Group 4 from the Coordinator will not be responded to.
- The User may add the Coordinator to Group 0x0004 as well by repeating the steps outlined above, and send messages to it from the Router by pressing the Router's RB5/RD7 push button.

The application works bi-directionally – i.e. in exactly same way on all the ZigBee device types – Coordinators, Routers and Reduce Function End Devices.

### ***Summary of Push Button Operation:***

**Button: RB4/RD6:** Adds a node to, or removes a node from Group 0x0004. The Group ID 0x0004 is hard coded in the application.

**Led: RA0/D10:** Used to indicate if a node is a member of Group 0x0004 (ON – yes; OFF – no)

**At startup the devices are not in any group, and the LEDs ON to indicate the device are on the network.**


**Button: RB5/RD7 :** Is used to send a messages to nodes in Group 0x0004. The actual message is a request for all the Group 0x0004 nodes to send back to the requester 10 bytes.

**Led: RA1/D09 :** Toggles to indicate that the receiving node is in Group 0x0004 and received requests for data.


### ***Running the Applications Via The Hyper-Terminal Console***

To operate the application from the hyper terminal menu system please do the following:

1. Follow steps 1 to3 from the Operating via Pushbutton section to get the devices load with the firmware and joined onto a network.
2. Connect a RS-232 cable from the Coordinator device to the PC.
3. Open up a Hyper Terminal window on the PC to the COM port to which the RS-232 is connected. The Hyper-terminal configuration should be:
  - Baud Rate: 19200
  - Data bits: 8-bits
  - Parity: None
  - Stop bits 1
  - Flow Control: None



4. Hit the Carriage Return/Line Feed <Enter> Key and the following menu system will be displayed on the PC console.  
Note the seven menu options 1 - 7 that are available.




5. Please press the <MCLR> button on the Router device. This will force the Router to rejoin the network. Note the 16-bit Network and the 64-bit MAC addresses of Router are displayed on the Coordinator's console. In a typical two device network, the network address of the Router is 0x0001.
  
6. To request data from the Router via the Coordinator menu, do the following:  
 From the menu select menu option < 2 >:  
**2: Request Data From Another Device**  
**How many bytes are you requesting(hex): 0a**  
**What is the short address of device you want data from: 0001**  
 or whatever the network address of the router is  
 This will send a data request to the Router via a unicast – directly and only to the Router asking for 0x0a bytes of data to be returned.

The response from the Router will be:

**Len: 0a**  
**From Address:: 0001**  
**00000102030405060708090A**

i.e. A payload of length 0x0a bytes is returned from the device at network address 0001, followed by the raw payload bytes that was requested. The payload is preceded by a one-byte status byte which has a value 00.



7. To request data from a devices that are members of a particular group do the following:
  - Press and release the RB4/RD6 button on the Router device several times. Observe that the RA0/D10 LED toggling on/off as RB4/RD6 is pressed and released. Press and release the RB4/RD6 button such that RA0/D10 remains ON after the button is released. This will place the Router in Group 0x0004.
  - From the Coordinator menu select menu option <3>  
**3. Please enter the Group ID of the Data Request: 0004**

The response from the Router will be:

**Len: 0a**  
**From Address:: 0001**  
**0000010203040506070809**

The Router is part of Group 0x0004 so it responds with the above information.

8. To send data directly to the Router from the Coordinator menu use menu option <4>:  
**4: Request Data From Another Device**  
**Please enter the number of bytes to send (hex): 0a**  
**Please enter the short address of the destination device: 0001**  
 This will send ten bytes of data directly to Router. The Coordinator will display: **Message sent successfully**. Observe the traffic on Zena to confirm that the message is successfully sent.

9. To add the Coordinator to Group 0x0004, do the following from the Coordinator menu. Select menu option 6.  
**6: Add/Remove Device to/from a Group**  
**What Group Activity do you want to do ?**  
**0=Add Device to a Group**  
**1=Remove Device from a Group**  
**2=Remove Device from All Groups: 0**

**Enter 16-bit Group ID (Hex): 0004**

this will add the Coordinator to Group ID 0x0004. Now by pressing the RB5/RD7 on the Router will result in the Coordinator responding by sending 10 bytes of data back to the Router.


Use the same menu and choose sub-option 1 or 2 to remove the Coordinator from a Group.

10. To see what devices are currently stored in the Coordinator's Neighbor Table choose menu option '7' on the Coordinator menu:

### 7: Dump Neighborhood Information

The information that will be displayed is the following -

Short	MAC	Type	Rntlship
0001	0000000100000000	RTR	CHILD



This means that the Router with the noted network address **0001** and MAC address **0000000100000000** is a child of the Coordinator.

As more devices join the network, this table will contain more entries.

## FAQs

Index	Symptom	Solution
1	The LEDs are OFF on Coordinator	Press the <mclr> button to reset the Coordinator node
2	The LEDs are OFF on Router/RFD node	First reset the Coordinator, followed by resetting the node.
3	No Traffic on Zena	Ensure that Zena is operating on channel 26.  Ensure that the Coordinator has formed the network by connecting a hyper terminal and hitting the <CR><LF> several times until the menu is displayed on the Coordinator.  Press and release the RB5/RD6 push-button on the node.
4	No data is received from another node when RB5/RD6 is pressed and released	Ensure that at least one other node on the network is a member of Group 0x0004
5	The RFD LEDs are not blinking	The RFD has lost contact with its parent. Move RFD node closer to a Coordinator/Router node that is on the network and pressed the <mclr> button.

## TRADEMARKS

*The Microchip name and logo, the Microchip logo, MPLAB, and PIC are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.*

*PICDEM, PICTail and MiWi are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.*

*IEEE 802.15.4 is registered trademarks of IEEE 802.15 working group*