



All these signals should be "diff-paired" with ground

09185406904

Place the 1uF cap near to the ERNI connector

Place the 1uF caps approx every 10cm along the diff pair

Place the Net-Ties close to the 1812 capacitor

Title			
Size: A3	Project:	Rev: A.00	
Date: 05/10/2016	Time: 17:51:07	Sheet	1 of 1
File:			