



Ethernet



**Very Important**

- 1.in default Mode 100nF capacitors should be connect between CHSGND and Eth\_AGND
- 2.if method 1 doesn't work use ferrit bead between CHSGND and Eth\_AGND
- 3.if both of them don't work use ferrit bead between CHSGND and Eth\_GND

Title		
Size A2	Number	Revision
Date: 5/9/2014	Sheet of	
File: E:\P\TH\Ethernet W5300 SchDoc	Drawn By	