



Measurement with clamp current meter

Check only in or out current

Measuring device reacts and show sum of magnetic fields inside clamp ("jaws ") area.



Measure clamp area $I_{TOTAL} = I_L - I_L = 0$



Measure clamp area $I_{TOTAL} = I_L$