

VIN = 17 to 32V

LOAD  
12V, 30A

SLOPE  
COMPENSATION

SLOPE  
COMPENSATION

SLOPE  
COMPENSATION

COMPONENTS ARE PURELY ERROR  
DEMONSTRATIVE OF THE AMP  
INTERLEAVING, NOT CORRECT  
COMPONENTS IN ALL CASES.