Mains Distribution Device

Measure Live/Neutral imbalance current

Measure Live current

240VAC Mains

L

N

E

Relay

Measure V

Measure Earth Current

To Load