

作成承認印

配布許可印

**Nikon****COOLPIX L18**

VMA17003 (Silver)

VMA17113 (Black)

VMA17313 (Blue)

VMA17413 (Red)

PARTS LIST

修理部品表

**Nikon** | **NIKON CORPORATION**  
Tokyo, Japan

Copyright © 2008 by Nikon Corporation.

All Rights Reserved.

無断転載を禁ず !!

0592-4342-60000 (5) VMA17003  
0592-4342-60010 (5) VMA17113  
0592-4342-60010 (5) VMA17313  
0592-4342-60000 (5) VMA17413

0299-9042-60050 (1) VMA17003  
0299-9042-60170 (1) VMA17113  
0299-9042-60180 (1) VMA17313  
0299-9042-60190 (1) VMA17413

0512-0511-70422x2 (10)

0692-1042-60990 (5) 798002-  
0692-1042-60890 (5) 798000-  
0692-1042-60090 (5) 298000-  
0692-1042-61290 (5) 598000-  
0692-1042-61090 (5) 598002-  
0692-1042-60390 (5) 398000-  
~~0692-1039-60390 (5) 398000-~~ △  
0692-1042-60190 (5) 398010-  
0692-1042-60790 (5) 798007-  
0692-1042-60690 (5) 798005-  
0692-1042-60590 (5) 498002-  
0692-1042-60490 (5) 498000-

0299-9042-60040 (1) VMA17003  
0299-9042-60160 (1) VMA17113  
0299-9042-60040 (1) VMA17313  
0299-9042-60040 (1) VMA17413

0512-0811-40313x2 (10)

0299-9042-60090 (1)

0512-0511-70422x6 (10)

0299-9042-60100 (1)

0592-7142-62000(5)

0512-0811-40313x2 (10)

0592-6242-62000 (5)

0592-4342-61000 (5) VMA17003  
0592-4342-61010 (5) VMA17113  
0592-4342-61010 (5) VMA17313  
0592-4342-61000 (5) VMA17413

0299-9042-60030 (1) VMA17003  
0299-9042-60130 (1) VMA17113  
0299-9042-60140 (1) VMA17313  
0299-9042-60150 (1) VMA17413


0692-1321-5A090 (5)

0512-0511-70422x3 (10)

0512-0511-70422 (10)

0592-6442-60000 (5)



















0299-9042-60010 (1) VMA17003  
0299-9042-60200 (1) VMA17113  
0299-9042-60210 (1) VMA17313  
0299-9042-60220 (1) VMA17413



## Parts List

COOLPIX L18 (Silver)

















VMA17003-R.3746.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs/ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
0299-9042-60010 0299-9042-60010		電池蓋部組 BATTER COVER UNIT	1	1		1	
0299-9042-60020 0299-9042-60020		メイン基板部組 MAIN PCB UNIT	1	2		1	
0299-9042-60030 0299-9042-60030		前カバー部組 FRONT COVER UNIT	1	1		1	
0299-9042-60040 0299-9042-60040		中間カバー部組 MIDDLE COVER UNIT	1	1		1	
0299-9042-60050 0299-9042-60050		後カバー部組 REAR COVER UNIT	1	1		1	
0299-9042-60060 0299-9042-60060		コンデンサー部組 CONDENSER UNIT	1	2		1	
0299-9042-60070 0299-9042-60070		LED LED	1	2		5	
0299-9042-60080 0299-9042-60080		シャーシ部組 CHASSIS UNIT	1	2		1	
0299-9042-60090 0299-9042-60090		LCDパネルユニット TFT LCD UNIT	1	1		1	
0299-9042-60100 0299-9042-60100		ブラケット部組 LCD BRACKET UNIT	1	1		1	
0299-9042-60110 0299-9042-60110		スピードライト基板部組 SB PCB UNIT	1	2		1	
0299-9042-60120 0299-9042-60120		フラッシュ部組 FLASH UNIT	1	2		1	
* 0330-4030-60050 0330-4030-60050		トリガーコイル TRIGGER COIL	1	2	0299-9042-60110	5	
△ 0363-0070-09102 0363-0070-09102		コード WIRE	1	2		5	RP08014
△ 0363-0090-10101 0363-0090-10101		コード WIRE	1	2		5	RP08014
* 0372-1302-00050 0372-1302-00050		ヒューズ 2A/32V FUSE 2A/32V	2	2	0299-9042-60020	5	
0386-1040-40009 0386-1040-40009		タッチSW TOUCH SW	1	2	0299-9042-60110	5	
0512-0511-70373 0512-0511-70373		ネジ SCREW	2	2		10	

## Parts List

COOLPIX L18 (Silver)

VMA17003-R.3746.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 0512-0511-70422 0512-0511-70422		ネジ SCREW	16	1,2		10	
0512-0811-40313 0512-0811-40313		ネジ SCREW	4	1		10	
0512-2611-70252 0512-2611-70252		ネジ SCREW	1	2		10	
0592-4342-60000 0592-4342-60000		USBカバー USB COVER	1	1		5	
0592-4342-61000 0592-4342-61000		AC電源カバー AC POWER UNIT	1	1		5	
0592-6242-62000 0592-6242-62000		吊環 RING STRAP	1	1		5	
0592-6442-60000 0592-6442-60000		軸 SHAFT	1	1		5	
* 0592-7137-94000 0592-7137-94000		マイラーテープ MYLAR TAPE	1	2		5	
0592-7142-61000 0592-7142-61000		マイラーテープ MYLAR TAPE	1	2		5	
0592-7142-62000 0592-7142-62000		マイラーテープ MYLAR TAPE	1	1		5	
0592-7242-63000 0592-7242-63000		ラゲ板 LAG PLATE	1	2		5	
0592-7342-60000 0592-7342-60000		両面テープ ADHESIVE DOUBLE COATED TAPE	1	2		5	
0592-7442-63000 0592-7442-63000		モルト SPONGE	1	2		5	
0592-7442-64000 0592-7442-64000		ワッシャー WASHER	2	2		10	
0592-7442-65000 0592-7442-65000		モルト SPONGE	1	2		5	
0692-1042-60090 0692-1042-60090		製品番号シール298- SERIAL NUMBER STICKER 298-	0-1	1		5	
0692-1042-60490 0692-1042-60490		製品番号シール498- SERIAL NUMBER STICKER 498-	0-1	1		5	

**COOLPIX L18 (Silver)**









**COOLPIX L18 (Black)**

- 4 -

## Parts List

**COOLPIX L18 (Blue)**

**VMA17313-R.3746.A**

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 0299-9042-60040		中間カバー部組	1	1		1	
0299-9042-60040		MIDDLE COVER UNIT					
0299-9042-60140		前カバー部組	1	1		1	
0299-9042-60140		FRONT COVER UNIT					
0299-9042-60180		後カバー部組	1	1		1	
0299-9042-60180		REAR COVER UNIT					
0299-9042-60210		電池蓋部組	1	1		1	
0299-9042-60210		BATTERY COVER UNIT					
* 0592-4342-60010		USBカバー	1	1		5	
0592-4342-60010		USB COVER					
* 0592-4342-61010		AC電源カバー	1	1		5	
0592-4342-61010		AC POWER UNIT					



**COOLPIX L18 (Red)**

△